

Clearance Light Kits

INSTALLATION INSTRUCTIONS

READ ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLATION

⚠ WARNING: The attachment and installation of this product is beyond the control of Winston Products, LLC. Winston Products, LLC is not responsible for the attachment or the installation of this product. Winston Products, LLC is not liable for damages and/or injuries that are the result of improper use/attachment or are the result of use beyond the intended towing application. The liability of this product is limited to the purchase price if it proves to be defective in material and/or workmanship. Any and all warranties, explicit or implied, are void if the product is damaged or worn.

⚠ WARNING: Consult vehicle and trailer owner's manual before installation. Check for sensors, wires, or components behind the mounting surface prior to installation.

INSTALLATION INSTRUCTIONS

1. Disconnect power supply.
2. Select suitable light mounting location.
3. Mark the two outside mounting holes for the light bracket and drill holes.
4. Connect the black lead wire to the taillight circuit.
NOTE: For proper light function a ground connection must be achieved.
5. Remove protective film from the adhesive pad on the back of the grommet and attach to the mounting bracket.
6. Securely mount the light bracket to the vehicle.
7. Reattach the lens and secure light into place.
8. Reconnect vehicle power supply.
9. Test lights.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT WWW.TOWSMART.COM.



A Winston Products Company
TOWSMART.COM
WINSTON PRODUCTS, LLC.
30339 Diamond Parkway
Cleveland, OH 44139